



## Meaning of Tactile Symbols on Vantiva CPE Products



**Fiber:** Fiber-optic network connection. Connects the device to a fiber internet service.



**DSL:** Digital Subscriber Line connection. Connects the device to a telephone line for DSL internet.



**Reset:** Reset button. Restarts the device or restores factory settings when held.



**WPS:** Wi-Fi Protected Setup. Allows quick wireless connection without a password.



**LAN:** Local Area Network port. Connects devices using an Ethernet cable.



**WAN:** Wide Area Network port. Connects the device to an external modem or internet source.



**USB:** Universal Serial Bus port. Used for storage devices or peripherals.



**DC Jack:** Direct-current power input for the device.



**Type C:** USB Type-C connector for power or data, depending on the model.



**Power Button:** Turns the device on or off.



**Optical SPDIF:** Sony Philips Digital interface. Used for sending digital audio data to an amplifier.



**RF:** Radio-frequency connector for antenna or cable television signals.



**HDMI:** High-Definition video and audio output to a TV or monitor.



**SIM:** Slot for SIM card enabling mobile network connectivity.



**Video:** Analog video output connector.



**Audio R:** Right-channel audio output.



**Audio Left:** Left-channel audio output.



**SFP Cage:** Slot for removable fiber or network module (Small Form-factor Pluggable).



**RJ11 (Phone):** Connector for a telephone or phone line.



**WiFi:** on/off button



**WPS or Wi-Fi:** on/off button