

SAFETY INSTRUCTIONS AND REGULATORY NOTICES

IP Set-Top Box UIW4084DU

This product must be installed in strict accordance with the manufacturer's instructions as described in the user documentation that is included with your product. Any change or modification made to this product that is not expressly approved by Vantiva will result in the loss of product warranty and may void the user's authority to operate this equipment. Vantiva disclaims all responsibility for any use that does not comply with these instructions.



Important Safety Instructions

- This product is intended to be used indoors in a residential or office environment. The ambient temperature must not exceed 45°C.
- Always install the product as described in the documentation that is included with your product.
- Do not use this product to report a gas leak in the vicinity of the leak.
- Must be installed in a pollution degree 2 environment (dry, non-conductive pollution only).
- Avoid using this product during an electrical storm. There may be a remote risk of electric shock from lightning.
- Remove all packaging material before applying power to the product. Plastic bags pose a suffocation risk—keep out of reach of children.
- Place and use the product only in positions as described in the user documentation that is included with your product.
- Never push objects through the openings in this product.
- Do not block or cover any ventilation openings; never stand it on soft furnishings or carpets.
- Do not touch metal parts of the product or accessories connected to USB ports—they may become hot during prolonged use or malfunction (burn risk). Turn off the product and let it cool before touching.
- Leave at least 10 cm around the product to ensure that proper ventilation gets to it.
- Do not install the product near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Do not put anything on it which might spill or drip into it (for example, lighted candles or containers of liquids). Do not expose it to dripping or splashing, rain or moisture. If a liquid enters inside the product, or if the product has been exposed to rain or moisture, unplug it immediately and contact your supplier or customer service.
- The Remote Control contains disposable batteries. There is danger of explosion if the batteries are mishandled or incorrectly replaced. Do not disassemble, crush, puncture, short the external contacts, dispose of in fire, or expose to fire, water or other liquids. Do not attempt to recharge disposable or non-reusable batteries. Replace batteries with the same or equivalent type. Do not expose batteries to excessive heat (such as sunlight or fire) and to temperatures above 100 °C (212 °F).
- Unplug this product from the wall socket and disconnect from all other devices before cleaning. Use a damp cloth for cleaning. Do not use liquid cleaners or aerosol cleaners.
- Do not use this product near water, for example near a bathtub, washbowl, kitchen sink, laundry tub, in a wet basement or near a swimming pool. Transition of the product from a cold environment to a warm one may cause condensation on some of its internal parts. Allow it to dry by itself before using the product.
- Use only the power adapter provided with the product by your service provider or local supplier, or a replacement provided by them. Use of other adapters is prohibited.
- The power connections to the product and the mains supply socket outlet socket must be accessible at all times, so that you always can disconnect the product quickly and safely from the mains supply.
- Do not overload outlets or extension cords, this increases fire or shock risk. Always unplug before moving the product or connecting/disconnecting cables.
- Keep away from interference sources for optimal performance (e.g., microwave ovens, cordless phones, gaming consoles, amplifiers, speakers, soundbars).
- Do not use the device at altitudes above 3000m.
- Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- Only use attachments/accessories specified by the manufacturer.

Symbols Used

The following symbols may appear on or within this product and its accompanying accessories:

Symbol	Indication
	This symbol is intended to alert that uninsulated voltage within this product may have sufficient magnitude to cause electric shock. Therefore, it is dangerous to make any kind of contact with any inside part of this product.
	This symbol is intended to alert you of the presence of important operating and maintenance (servicing) instructions in the documentation that is included with your product.
	This symbol indicates for indoor use only (IEC 60417-5957).
	This symbol indicates Double insulated Class II equipment (IEC 60417-5172). Does not require an earth connection.
	This symbol indicates Alternating Current (AC).
	This symbol indicates Direct Current (DC).
	This symbol indicates Electrical polarity.

Limiting Human Exposure to RF Electromagnetic Fields

This product is equipped with wireless radio transceivers. The radio transmit power per transceiver is limited according to regulatory region.

The frequencies bands and the maximum powers of the transceivers this product is equipped with are indicated in the user documentation that is included with your product. This product must be installed and used at a minimum distance of 20 cm between it and any person's body (including hands, wrists, feet and ankles).

Servicing



To reduce the risk of electric shock, do not disassemble this product. Dry your hands before handling the product (shock risk).

Unplug the product and refer servicing to qualified personnel if:

- The power adapter, cord, or plug are damaged.
- Supplied cords are damaged or frayed.
- Liquid has been spilled on the device.
- The product has been exposed to rain or water.
- The product does not operate normally.

- The product has been dropped or damaged.
- There are signs of overheating.
- The product shows a significant change in performance.
- The product emits smoke or a burning smell.

Open Source Software notification

The software of this product may contain certain open source software modules which are subject to Open Source Software license terms (see <https://opensource.org/osd> for definition). Such Open Source Software components and/or versions may change in the future versions of the software product.

A list of the Open Source Software used or provided as embedded into the current software of the product and their corresponding licenses and version number are, to the extent required by applicable terms, available on Vantiva's website at the following address:


www.vantiva.com/opensource or at another address as Vantiva may provide from time to time. If and where applicable, depending on the terms of the applicable Open Source Software licenses, the source code of the Open Source Software is available for free upon request. For avoidance of doubt, Open Source Software is only licensed by the original owner of the Open Source Software under the terms set forth in the designated Open Source License.

Vantiva Technologies, 10 boulevard de Grenelle
75015, Paris – France
vantiva.com



Scan the QR code to view or download digital versions of the product documents.

Connections



HDMI (TV)	HDMI OUT (1m50 ULTRA HDMI cable supplied with the equipment)	1
Ethernet	(3m00 Cat5E STP Ethernet cable supplied with the equipment)	2
Power Switch Button	Push button	3
DC Power Input	USB Type-C connector	4
Reset Switch	On base	5
USB	USB 2.0 (Type A)	6
Bluetooth	Frequency Band: 2400 – 2483.5 MHz Maximum power (EIRP): 7+/-3dBm	
Wi-Fi	Frequency Band: 5150 – 5350 MHz, Maximum power (EIRP): 20 +/- 3dBm Frequency Band: 5470 – 5725 MHz, Maximum power (EIRP): 27 +/- 3dBm Frequency Band: 5725 – 5875 MHz, Maximum power (EIRP): 27 +/- 3dBm	

Technical Specifications

Operating Voltage	100-240 V AC ~ 50/60 Hz
Typical Power Consumption	<15W Max
Deep standby Power Consumption	<0.5W
Weight	153.5g
Dimension (L x W x H)	110 x 110 x 27 mm
Operating Temperature Range	0°C to +40°C
Storage Temperature Range	-25°C to +55°C
Remote Control Battery Type	2 batteries AAA 1.5V
Input Voltage / Current	5V DC / 3A



6361345B

تعليمات السلامة والإشعارات التنظيمية

جهاز استقبال IP طراز UIW4084DU

يجب تركيب هذا المنتج بدقة وفقاً لتعليمات الشركة المصنعة، كما هو موضح في وثائق المستخدم المرفقة مع المنتج. أي تغيير أو تعديل يُجرى على هذا المنتج ولم توافق عليه Vantiva صراحةً سيؤدي إلى فقدان ضمان المنتج، وقد يُبطل صلاحية المستخدم في تشغيل هذا الجهاز. تُخلي Vantiva مسؤوليتها عن أي استخدام لا يتوافق مع هذه التعليمات.



تعليمات السلامة المهمة

- لا تضع أي شيء فوق المنتج قد ينسكب أو يتسرب إليه (مثل الشموع المضاءة أو أوعية السوائل). لا تعرض المنتج للتقطر أو الرذاذ أو المطر أو الرطوبة. إذا تسرب سائل داخل المنتج، أو إذا تعرض المنتج للمطر أو الرطوبة، فافصله عن الكهرباء فوراً واتصل مع المورد أو خدمة العملاء.
- يحتوي جهاز التحكم عن بُعد على بطاريات غير قابلة لإعادة الشحن. هناك خطر انفجار في حال التعامل غير السليم مع البطاريات أو استبدالها بشكل غير صحيح. لا تقم بتفكيك البطاريات، أو سحقها، أو ثقبها، أو تقصير أطرافها الخارجية، أو التخلص منها في النار، أو تعريضها للنار أو الماء أو أي وسائل أخرى. لا تحاول إعادة شحن البطاريات غير القابلة لإعادة الاستخدام. استبدل البطاريات بنوع مماثل أو مكافئ. لا تعرض البطاريات لحرارة مفرطة (مثل أشعة الشمس أو النار) أو لدرجات حرارة تتجاوز 100 درجة مئوية (212 درجة فهرنهايت).
- افصل هذا المنتج عن مأخذ الحائط وافصله عن جميع الأجهزة الأخرى قبل التنظيف. استخدم قطعة قماش مبللة للتنظيف. لا تستخدم منظفات سائلة أو منظفات بخاخة.
- لا تستخدم هذا المنتج بالقرب من الماء، كان يكون قرب حوض استحمام، أو مغسلة، أو حوض مطبخ، أو حوض غسيل، أو في قبة رطب، أو بالقرب من مسبح. قد يؤدي انتقال المنتج من بيئة باردة إلى بيئة دافئة إلى تكثف تكاثف على بعض أجزائه الداخلية. اترك المنتج ليبرد تلقائياً قبل استخدامه.
- استخدم فقط محوّل الطاقة المرفق مع المنتج من مزود الخدمة أو المورد المحلي، أو بديلاً موثقاً منهما. يُمنع استخدام محوّلات أخرى.
- يجب أن تظل توصيلات الطاقة الخاصة بالمنتج ومأخذ التيار الكهربائي الرئيسي قابلة للوصول في جميع الأوقات، حتى تتمكن دائماً من فصل المنتج عن مصدر التيار الكهربائي بسرعة وأمان.
- لا تحلّل المأخذ الكهربائيّة أو أسلاك التمديد فوق طاقتها، فهذا يزيد من خطر الحريق أو الصعق الكهربائي. احرص دائماً على فصل الجهاز عن الكهرباء قبل نقل المنتج أو توصيل الكابلات أو فصلها.
- أبقِ الجهاز بعيداً عن مصادر التداخل للحصول على أفضل أداء (مثل أفران الميكروويف، والهواتف اللاسلكية، وأجهزة الألعاب، ومضخّات الصوت، ومكبرات الصوت، وأنظمة الصوت الشريطية).
- لا تستخدم الجهاز على ارتفاعات تتجاوز 3000 متر.
- احص سلك الطاقة من الدوس عليه أو انحصاره، خصوصاً عند القوابس، والمأخذ الملائمة، ونقطة خروجه من الجهاز.
- استخدم فقط الملحقات/الإكسسوارات التي تحدّثها الشركة المصنّعة.

- هذا المنتج مُخصّص للاستخدام الداخلي في البيئات السكنية أو المكتبية. يجب ألا تتجاوز درجة حرارة المحيط 45 درجة مئوية.
- احرص دائماً على تركيب المنتج وفق ما هو موضح في الوثائق المرفقة معه.
- لا تستخدم هذا المنتج للإبلاغ عن تسرب غاز بالقرب من موقع التسرب.
- يجب تركيبه في بيئة من درجة التلوث 2 (تلوث جاف وغير موصّل للكهرباء فقط).
- تجنّب استخدام هذا المنتج أثناء العواصف الرعدية. قد يوجد خطر بعيد الاحتمال للصعق الكهربائي الناتج عن الصواعق.
- ازل جميع موادّ التغليف قبل توصيل الطاقة بالمنتج. تشكّل الأكياس البلاستيكية خطر اختناق — يُرجى إبعادها عن متناول الأطفال.
- صنع المنتج واستخدمه فقط في الأوضاع الموضحة في وثائق المستخدم المرفقة معه.
- لا تدخل أبداً أي أجسام عبر فتحات هذا المنتج.
- لا تسد أو تغطّ فتحات التهوية، ولا تضع الجهاز أبداً على مفروشات ناعمة أو سجاد.
- لا تلمس الأجزاء المعدنية للمنتج أو الملحقات المتصلة بمنافذ USB — فقد تسخن أثناء الاستخدام المطوّل أو في حال حدوث عطل (خطر حروق). أوقفت تشغيل المنتج ودعه يبرد قبل لمسه.
- اترك مسافة 10 سم على الأقلّ حول المنتج لضمان وصول التهوية المناسبة إليه.
- لا تترك المنتج بالقرب من أي مصادر حرارة، مثل أجهزة التدفئة، أو فتحات التدفئة، أو المواقد، أو أي أجهزة أخرى (بما في ذلك مضخّات الصوت) تُنتج حرارة.

الرموز المستخدمة

قد تظهر الرموز التالية على هذا المنتج أو داخله، وعلى الملحقات المرافقة له:

- إذا سقط المنتج أو تعرّض للتلف.
- إذا ظهرت علامات ارتفاع مفرط في درجة الحرارة.
- إذا أظهر المنتج تغييرًا ملحوظًا في الأداء.
- إذا انبعث من المنتج دخان أو رائحة احتراق.

إشعار البرمجيات مفتوحة المصدر

قد يحتوي برنامج هذا المنتج على وحداث برمجية مفتوحة المصدر تخضع لشروط ترخيص البرمجيات مفتوحة المصدر (راجع <https://opensource.org/osd> للاطلاع على التعريف). قد تتغير هذه المكونات و/أو الإصدارات من البرمجيات مفتوحة المصدر في الإصدارات المستقبلية من المنتج البرمجي. نتوفر، بالقدر الذي تقتضيه الشروط المعمول بها، قائمة بالبرمجيات مفتوحة المصدر المستخدمة أو المضمنة في البرنامج الحالي للمنتج، مع تراخيصها وأرقام إصداراتها المقابلة، على موقع Vantiva الإلكتروني على العنوان التالي: www.vantiva.com/opensource أو على عنوان آخر قد توفره Vantiva من وقت لآخر. إذا كان ذلك منطبقًا، ووفقًا لشروط تراخيص البرمجيات مفتوحة المصدر المعمول بها، يتوفر الكود المصدري لهذه البرمجيات مجانًا عند الطلب. ولتجنب أي التباس، لا تُرخص البرمجيات مفتوحة المصدر إلا من قِبل المالك الأصلي لها، وفقًا للشروط المنصوص عليها في ترخيص المصدر المفتوح المحدد.

Vantiva Technologies, 10 boulevard de Grenelle
75015, Paris – France
vantiva.com



امسح رمز الاستجابة السريعة (QR) لعرض النسخ الرقمية من وثائق المنتج أو تنزيلها.

الرمز	الدلالة
	يهدف هذا الرمز إلى التنبيه إلى أن الجهد الكهربائي غير المعزول داخل هذا المنتج قد يكون كافيًا للتسبب في صدمة كهربائية، لذا، من الخطر لمس أي جزء داخلي من هذا المنتج بأي شكل من الأشكال.
	يهدف هذا الرمز إلى تنبيهك إلى وجود تعليمات تشغيل وصيانة مهمة في الوثائق المرفقة مع المنتج.
	يشير هذا الرمز إلى أن الاستخدام مخصص للأماكن الداخلية فقط (IEC 60417-5957).
	يشير هذا الرمز إلى أن الجهاز من الفئة الثانية مزدوجة العزل (IEC 60417-5172). لا يتطلب توصيلًا أرضيًا.
	يشير هذا الرمز إلى التيار المتردد (AC).
	يشير هذا الرمز إلى التيار المستمر (DC).
	يشير هذا الرمز إلى القطبية الكهربائية.

الحذ من تعرّض الإنسان للحقول الكهرومغناطيسية (RF) الترددية


هذا المنتج مزودٌ بأجهزة إرسال واستقبال لاسلكية. تكون قدرة الإرسال اللاسلكي لكل جهاز إرسال واستقبال محدودة وفقًا للمنطقة التنظيمية. تُذكر نطاقات الترددات، والحُد الأقصى لقدرة أجهزة الإرسال والاستقبال المزود بها هذا المنتج، في وثائق المستخدم المرفقة معه. يجب تركيب هذا المنتج واستخدامه على مسافة لا تقل عن 20 سم بينه وبين جسم أي شخص (بما في ذلك اليدين، والمعصمين، والقدمين، والكاحلين).

الصيانة

للحد من خطر الصعق الكهربائي، لا تقم بتفكيك هذا المنتج. جيّف يديك قبل التعامل مع المنتج (خطر الصعق الكهربائي).

افصل المنتج عن الكهرباء واطلب الصيانة من فنيين مؤهلين في الحالات التالية:

- إذا كان محوّل الطاقة أو السلك أو القابض تالفًا.
- إذا كانت الأسلاك المرفقة تالفة أو مهترنة.
- إذا انسكب سائل على الجهاز.
- إذا تعرّض المنتج للمطر أو الماء.
- إذا لم يعمل المنتج بشكل طبيعي.



1	منفذ HDMI OUT (كابل ULTRA HDMI بطول 1.50 متر مرفق مع الجهاز)	HDMI (التلفاز)
2	(كابل إيثرنت Cat5E STP بطول 3 أمتار مرفق مع الجهاز)	إيثرنت (Ethernet)
3	زر ضغط	زر مفتاح التشغيل
4	منفذ USB من نوع Type-C	مدخل طاقة التيار المستمر (DC)
5	على القاعدة	مفتاح إعادة الضبط
6	USB 2.0 (من نوع Type A)	USB
	نطاق التردد: 2400 – 2483.5 ميجاهرتز ، الحد الأقصى للقدرة (EIRP): 3 ± 7 ديسيبل ميلي واط	بلوتوث (Bluetooth)
	نطاق التردد: 5150 – 5350 ميجاهرتز ، الحد الأقصى للقدرة (EIRP): 3 ± 20 ديسيبل ميلي واط نطاق التردد: 5470 – 5725 ميجاهرتز ، الحد الأقصى للقدرة (EIRP): 3 ± 27 ديسيبل ميلي واط نطاق التردد: 5725 – 5875 ميجاهرتز ، الحد الأقصى للقدرة (EIRP): 3 ± 27 ديسيبل ميلي واط	واي فاي (Wi-Fi)

المواصفات الفنية

جهد التشغيل	100-240 فولت تيار متردد ~ 50/60 هرتز
استهلاك الطاقة النموذجي	> 15 واط كحد أقصى
استهلاك الطاقة في وضع الاستعداد العميق	> 0.5 واط
الوزن	153.5 غرام
الأبعاد (الطول × العرض × الارتفاع)	$110 \times 110 \times 27$ مم
نطاق درجة حرارة التشغيل	من 0 درجة مئوية إلى 40 درجة مئوية
نطاق درجة حرارة التخزين	من -25 درجة مئوية إلى +55 درجة مئوية
نوع بطارية جهاز التحكم عن بُعد	بطاريّتان من نوع AAA بجهد 1.5 فولت
جهد / تيار الدخل	5 فولت تيار مستمر / 3 أمبير

